



# Einstein Solitaire Wizard

User's Guide



Model No.: E140

**C**ongratulations on your purchase of Einstein Solitaire Wizard. With this amazing hand held unit you will always have the fun of solitaire right in the palm of your hands.

Albert Einstein is probably best known for his famous formula,  $E=mc^2$ , but this German-born theoretical physicist made unparalleled contributions to modern scientific thought. In the field of physics, he introduced his special theory and general theory of relativity and, in 1921, his work on the photoelectric effect won him the Nobel Prize in Physics.

Please read this guide thoroughly, especially noting safety and care instruction. Keep this guide for reference.

ALBERT EINSTEIN and related rights <sup>TM</sup>/© of HUI, used under license.

## **Contents**

- 1 - Einstein Solitaire Wizard
- 1 - User's Guide

## **BATTERY INSTALLATION**

1. Turn the unit over and lay it face down on a soft surface such as a magazine or towel.
2. Use a small Phillips screwdriver to remove the battery compartment cover.
3. Insert 3 - AAA batteries, making sure to match the polarity (+ and -) as shown in the diagram inside the battery compartment.
4. Replace the battery compartment cover. Screw in firmly.

**If no button is pressed for several minutes, the unit will power-down to conserve battery life. Press ON/OFF to "wake" the unit.**

## **BUTTON FUNCTION**

### **ON/DEAL**

Press to turn on the unit.

Press during a game to deal a new card from the deck.

### **GAME**

Press this button to select between different types of games.

### **TIMER/UNDO**

Press to undo your last move.

### **SUIT**

Use to place cards in the suit spaces on the top right.

### **1, 2, 3**

Press this button when playing a Deal 3 game to look through the 3 cards dealt to you.

### **DECK**

Press during a game to select the card from the deck that is showing.

### **MUTE**

Use to turn the sound off and on.

### **RESET**

Use a small, pointed object like a pen to push this button when you need to return the unit to its default settings.

## **HOW TO PLAY SOLITAIRE WIZARD**

The object of the game is to complete the “foundations”, the four boxes in the upper right corner. Each foundation is built up by moving cards in order from Ace to King.

Turn the unit on and press GAME to cycle between the different types of games. The games are Standard Deal 1, Standard Deal 3, Vegas Deal 1 and Vegas Deal 3.

Press ON/DEAL when you are ready to begin your game.

### **MOVING CARDS**

To move cards from one column to another first press the number of the column from which you wish to move the card. Next press the number of the column you wish to move the card to.

### **MOVING CARDS TO THE SUIT STACK**

Select a card by using the numbers along the bottom or the deck button then press the suit button. This will automatically move the card to the correct suit stack.

## **SCORING SYSTEM**

### **STANDARD - DEAL 1 & DEAL 3**

Each game starts with 0 points.

- 10 points move each card from deck or card stack to suite stack
- 5 points move each card from deck to card stack
- 0 points move each card from card stack to card stack
- 15 points move each card from suite stack to a card stack

- 20 points Each pass through the deck (for Standard Deal 3 and Vegas Deal 3 game only).
- 100 points After 3 passes through the deck ( for Standard Deal 1 and Vegas Deal 1 game only).

#### VEGAS - DEAL 1 & DEAL 3

Each game starts at 500 points. If you decide to accumulate your scores in consecutive games, press REVIEW button before game starts, and the work “KEEP will appear on the screen.

- 52 points are deducted per game
- 5 points when you move each card to suit stack

#### STANDARD - WITH TIMER

If you select the timer option, a special bonus will be awarded if you win the game within a specific time of about 4.5 minutes.

- 2 points will be deducted automatically if you exceed 8 seconds after each move.

## SAFETY & CARE

- Do not submerge in water or other liquids.
- Do not disassemble the product for any reason.
- Do not expose to extreme temperatures.
- Do not drop, throw, smash or otherwise cause physical shock.
- Clean using only a slightly damp cloth.
- Do not use cleaners with chemical agents.

## BATTERY INFORMATION

- Do not short-circuit the battery terminals.
- Do not use rechargeable batteries.
- Do not mix old and new batteries.
- Remove exhausted batteries.
- Batteries should be installed and replaced by an adult only.
- Remove batteries when not in use.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.

## ABOUT ALBERT EINSTEIN

---

Born: March 14, 1879  
Ulm, Württemberg, Germany

Died: April 18, 1955 (aged 76)  
Princeton, New Jersey, USA

Residence: Germany, Italy,  
Switzerland, USA

Citizenship:  
German (1879-1896,1914-1933)  
Swiss (1901-1955)  
American (1940-1955)

### Notable Awards:

Nobel Prize in Physics (1921)  
Copley Medal (1925)  
R.A.S Gold Medal (1925)  
Max Planck Medal (1929)  
Benjamin Franklin Medal (1935)

### Honorary Doctorates:

Princeton (1921)  
Oxford (1931)  
Harvard (1935)

**“Great spirits have always found violent opposition from mediocrities. The latter cannot understand it when a man does not thoughtlessly submit to hereditary prejudices but honestly and courageously uses his intelligence.”**

This device complies with Part 15 of the FCC Rules Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Excalibur Electronics, Inc. reserves the right to make technical changes without notice in the interest of progress.**

## 90-DAY LIMITED WARRANTY

EXCALIBUR ELECTRONICS, INC., warrants to the original consumer that its products are free from any electrical or mechanical defects for a period of 90 DAYS from the date of purchase. If any such defect is discovered within the warranty period, EXCALIBUR ELECTRONICS, INC., will repair or replace the unit free of charge upon receipt of the unit, shipped postage prepaid and insured to the factory address below.

The warranty covers normal consumer use and does not cover damage that occurs in shipment or failure that results from alterations, accident, misuse, abuse, neglect, wear and tear, inadequate maintenance, commercial use, or unreasonable use of the unit. This warranty does not cover cost of repairs made or attempted outside of the factory.

Any applicable implied warranties, including warranties of merchantability and fitness, are hereby limited to 90 DAYS from the date of purchase. Consequential or incidental damages resulting from a breach of any applicable express or implied warranties are hereby excluded. Some states do not allow limitations on the duration of LIMITED 90-DAY WARRANTY implied warranties and do not allow exclusion of incidental or consequential damages, so the above limitations and exclusions in these instances may not apply. The only authorized service center in the United States is:

Excalibur Electronics, Inc.

13755 SW 119th Ave

Miami, Florida 33186 U.S.A.

Phone: 305.477.8080

Fax: 305.477.9516

[www.ExcaliburElectronics.com](http://www.ExcaliburElectronics.com)

Ship the unit carefully packed, preferably in the original carton, and send it prepaid, and adequately insured. Include a letter, detailing the complaint and including your daytime telephone number, inside the shipping carton. If your warranty has expired and you want an estimated fee for service, write to the above address, specifying the model and the problem.

NOTE: Please do not send your unit without first receiving an estimate for servicing from EXCALIBUR ELECTRONICS, INC. Contact us before sending your unit. We cannot store your unit!



# EXCALIBUR ELECTRONICS

---

13755 SW 119<sup>th</sup> Avenue  
Miami, Florida 33186

Phone: 305.477.8080

Fax: 305.477.9516

**Please Visit Us @**  
**[www.ExcaliburElectronics.com](http://www.ExcaliburElectronics.com)**

Einstein Solitaire Wizard MODEL No.: E140 082608